

GVC2 Service Mode Menu

1. Tube Fill / Coin Dispense
2. Motor Count (Resets Motors to home)
3. Options
 1. Force Vend (on/ OFF)
 2. Bill Escrow (ON /off)
 3. Multi Vend (on/ OFF)
 4. Free Vend (on/ OFF)
 5. Fast Change (on/ OFF)
 6. Optic Vend (1-Item/2-Row/3-All)
 7. POS (Default Message) (ON/off)
 8. Set Point (Temperature)
 9. Keypad Backlight (Level)
 0. Drop Sensor (Sensitivity)
4. Configuration
 1. Item 2. Row 3. All Items
 1. Can / Bottle / Snack
 4. Language
 5. Auto-reinstate 1. Item 2. Row 3. All (ON/off)
 6. Space-to-Sales (on/ OFF)
 1. Rows/Half Rows/2s/Machine/MZF/Custom
 7. Custom Space-to-Sales
 8. Time/Date
 1. Date 2. Time 3. Daylight Savings
 9. Health Safety
 1. Upper-MZF (ON / OFF) 1-Item/2-Row/3-All
 2. Lower (ON / OFF) 1-Item/2-Row/3-All
 9. Enable (ON/OFF)
 0. Advanced Config (See Next Column)
5. Pricing
 - 1-Item/2-Row/3-All
 4. Coupon (See Manual)
 5. Token (See Manual)
 7. Combo (See Manual)
6. Accounting
 1. Item 2. Row 3. All Items
 1. Historical Count 2. Historical Cash
 3. Resettable Count 4. Resettable Cash
 5. Historical Card 6. Historical 2nd Vends
 7. Resettable Card 8. Resettable 2nd Vends
 0. Clear Resettable 0. Clear ?
 5. Historical Cycle Elevator
 6. Resettable Cycle Elevator
 7. Historical Lift
 8. Resettable Lift
 9. Short form DEX (on/ OFF)
7. Advanced Options (Next Column)
8. Test Vend Item
9. Test Vend All Items
0. Diagnostics
 1. Machine Self Test
 2. Relay Test 1 2 3 4 5 6 (0-All Off)
 3. Log (Engineering)
 4. Coin Reject Rate
 5. Bill Reject Rate
 6. I-Vend Aligned
 7. Log (Engineering) – Password (2314)
 8. Door Menu
 1. Alert (on/OFF)
 2. Homing (on/OFF)
 3. Auto Service {ON/off}
 9. Refrigeration Menu
 1. Manual Defrost (on/ OFF)
 2. Temperature Log (1. Up - 7. Down)
 3. Event Log (1. Up - 7. Down)
0. Peripherals
 1. Elevator
 1. Elevator Board Software Version
 2. Manual Reset / Count Rows
 3. Open / Close Baffle
 4. Cycle Elevator (OFF/5 /10/15/1) Minute
 2. Auto Door (Open/Close)
 3. Lift Motor (Open/Close)
 6. Lift optics align
0. Advanced Configuration (Password: 2314)
 1. Beep (ON / off)
 2. Optics Disable (L-Vend Disables Vendor)
 3. Motor Type (2 WIRE / 3 Wire)
 4. Talker (on / OFF)
 5. Password Change
 6. Set Defaults
 1. Default 1 (Standard Default)
 2. Default 2 (Customer Specific Default)
 0. Reset Defaults
 7. Refrigeration Mode
(Snack, Cold, Cold Food, Slackened, Frozen, Dual Zone, Dual Upper -6, Chill, MZF, MZF-2, MZF-5, SZ Frozen, SZ Frozen-2, SZ Frozen-5, SZ cold, SZ cold-1)
Note: Use cold if no cold food
 8. 2 / 3 Digit Selection Style (Satellite Only)
0. Peripherals
 1. Elevator (on / OFF)
 2. Auto Lift Button (auto/off/BUTTON)
 3. Touch Comm (ON / off)
7. Advanced Options (Password: 2314)
 1. Discount (1-Item/2-Row/3-All)
 4. Day
 5. Start Time 5. Set Start Time
 6. Stop Time 6. Set Stop Time
 7. Discount Value
 9. Enable on / OFF
 2. Promo Vend (See Manual)
 3. Free Vend Rate (0 - OFF)
 4. Exact Change (Message Level)
 1. Amount (0.00 - Default)
 2. Alternate Change Rules (ON /off)
 5. Unconditional Accept (Level) (0.00 - OFF)
 6. Maximum Change
 1. Enable Max Change (on/ OFF)
 2. Set Amount (\$50.00 – Default)
 7. Programmable POS / Auxiliary
 1. POS (on/ OFF)
 2. Enter POS Message
 3. Auxiliary Messages (For Aux Language)
 4. Time Display (on/ OFF)
 8. Shutdown Machine
 - 1/2/3/4 Interval Number
 - 1-Item/2-Row/3-All
 4. Day
 5. Start Time 5. Set Start Time
 6. Stop Time 6. Set Stop Time
 8. Lighting (on/ OFF- hardware option)
 9. Enable (on/ OFF)
 9. Energy Savings
 1. Interval 1
 2. Interval 2
 4. Day
 5. Start Time 5. Enter Time
 6. Stop Time 6. Enter Time
 7. Target Temperature
 8. Lighting (ON / off- hardware option)
 9. Enable (on / OFF)
0. Motor Pairing (Item/Item)
Note: Must be odd/even motors and same tray